



Before Operation:

- Check plug and connection for proper function
- Make sure red emergency button is released
- Lock wheels in place In an X pattern

To Operate:

- Turn Black switch so white line points up. Remote should light up.
- Use only Green Start and Red Stop buttons to operate
- Use the remote dial to adjust speed.
- It is not optimal to run unit below “20.00”

