MiraColt

Basic operating instructions

Generation 3 and Generation 4. Read the full manual for your model before use. Plan rider suitability, positioning and assistance with a qualified medical professional.

Before starting

Inspect the seat, handlebar, cords, controller and protective panels or mesh. Keep the unit out of use if a part is loose, damaged or missing.

Use even, level ground. Angle the casters outward and lock all four. Keep hands, clothing, straps and objects clear of the moving-seat area.

With the main power switch Off, check the unit's electrical rating and connect power. Set the speed dial fully left. Check that the emergency shutoff is released when safe.

Have the rider settled and supported in a stable seated position before starting.

Start and control the motion

Turn the main power switch On. Use the green RUN key and turn the speed dial right slowly to increase motion. Match the activity and speed to the rider's plan.

Use only RUN, STOP/RESET and the speed dial. Do not use Reverse or change other controller settings.

Normal stop and shutdown

Press the red STOP/RESET key on the keypad and allow the motion to stop. For normal shutdown, stop the motor with this key before turning the main power switch Off.

Emergency or unexpected behavior

For an emergency, press the separate large red emergency shutoff. It stops the unit abruptly. Its location differs between models. Support the rider.

For unusual motion, noise or a controller fault, stop the session. Note any fault code and contact Chariot before further use. The large emergency shutoff is reserved for emergencies.

Support support@chariotinnovations.com | +1 254 651 6497

Full manual and videos chariotinnovations.com/operation/

Based on the November 2026 user manual. Quick reference - use alongside the full manual.